GETRIEBEBAU NORD

Member of the NORD DRIVESYSTEMS Group



Getriebebau NORD GmbH & Co. KG
Getriebebau-Nord-Straße 1 • 22941 Bargteheide, Germany • www.nord.com

SK CU4-MBR-C

Electronic brake rectifier

Part number: 275 271 510

NOTICE

Validity of this document

This document is only valid in combination with the operating instructions for the relevant electronic drive technology and under strict compliance with the safety and warning instructions which they contain. Safe commissioning of this module and the electronic drive technology depends on the availability of this information.

Scope of supply

1 x	Module	SK CU4-MBR-C
1 x	Mains voltage cable set	brown / black* * incl. fuse (5 A slow-acting)
1 x	24 VDC cable set	brown / blue
1 x	Connection cable (digital signal)	black
2 x	Connecting screws	M4 x 20, cross-head



Field of use

Electronic brake rectifier for installation in a decentralised electronic drive technology frequency inverter without own brake management (NORDAC *BASE* SK 180E / SK 190E, NORDAC *FLEX* SK 2x0E). With this module it is possible to directly control an electromagnetic brake of between 5 Nm and 150 Nm and a coil voltage of 105 V DC and 205 V DC.

Monitoring of the brake coil current is integrated.

The module has a water-repellent coating. Reliable operation is retained even with condensation.

Function description

The module must be supplied with 24 VDC.

The module can be operated with bridge or one way rectification and is designed for various mains and brake coil voltages. The brake is controlled via a digital input. Feedback of the brake status is output via a digital output. The module is equipped with a mains filter, which can be deactivated via a jumper.

Technical data

Temperature range

Temperature class	Class 3K3
Mains voltage	100 275 V AC ± 10 %
	(10 A)

-25°C ... 50 °C

Mains voltage	100 275 V AC ± 10 %
	(10 A)
	380 500 V AC ± 10 %
	(10 A)

Vibration resistance	3M7
Protection class	IP20

Brake current	≤ 0.5 A

Technical Information / Datasheet	SK CU4-MBR-C			
Electronic brake rectifier	TI 275271510	V 1.1	0523	en




For details of the electrical data please refer to the descriptions of the connections (Section "Control terminal details").

Installation

Installation location In defined option slot inside the NORDAC device.	
Fastening	with screw fastenings

Installation steps



Before carrying out installation step 1 it may be necessary to remove the control terminal bar (A), The control terminal bar (A) must be fitted after installation step 2.

Connections

Terminals Screw terminals		1 terminal bar with 16 connections, (5 mm spacing)
Cable cross section	0.142.5 mm	AWG 14-26
PE connection	Via device	Via screws for installation in the device

Control terminal details

Labelling, function

24 V Control voltage (input) GND: Reference potential for digital signals

DIN: Digital input MB: Brake control

DOUT: Digital output L: Mains connection for a phase

2 / 4 TI 275271510 - 0523



Connections, Functions

SK CU4-MBR-...


Labelling	Function	
		/e :
L2/N	2nd Phase	le le
L2/N	2nd Phase	enti
L1 _B	1st Phase (B)	~ Mains potential level:
L1 _B	1st Phase (B)	/ains
L1 _E	1st Phase (E)	~
L1 _E	1st Phase (E)	
		-
79	MB+	entia
		e pote level:
80	MB-	Brake potential level:
		ш
B5	DOUT	le/
C5	DIN	24 V DC potential level
40	GND	24 V tentia
44	24 V	p od



Compliance with the radio interference class C2 can only be ensured if the mains filter is active (jumper plugged into the upper position).

For use in non-earthed networks (IT network), the mains filter must be deactivated.

To do this, the jumper must be transferred from the top to the bottom.



Meaning, Functions		Description / Technical data			
Terminal			Parameter		
No.	Designation	Meaning	No.	Function of factory setting	
Cont	rol voltage	For the 24 V control voltage supp	oly to the mode	ule	
		24 V DC ± 25 % 50 500mA (according to load on the digital output)	Short circuit and limited excess temperature or overload monitoring available.		
44	24V	voltage (input)	-	-	
40	GND / 0V	Reference potential GND	-	-	
Digital inputs		Digital input for DC brake switching			
		10 27 V DC ± 10 % Switching thresholds ON: > approx. 8.5 V OFF: < approx. 7.5 V	•	A must be controlled by the frequency gital output (parameter P434) with the	
C5	DIN	Digital input	-	-	
Digital outputs		Reporting of the current status of the mechanical brake			
		SPS compatible in accordance with EN 61131-2 15 – 30 V DC, 200 mA	Low signal: 0 V High signal: 24 \		
B5	DOUT	Digital output	-	-	

TI 275271510 - 0523 3 / 4



Brake	e control	Output voltage	Output voltage for control of an electromagnetic brake.				
		Assignment of the the mains voltage:	Assignment of the brake depending on the mains voltage:		The output voltage depends on the supply voltage and the connection of the supply cable to the one-way (L1 _E) or		
		Mains 115 V AC 230 V AC 400 V AC 460/480 V AC Current: max. 0.5 A	Brake	bridge rectification (L1 _B) of the module. Output voltageFor one-way rectification 0.45 x mains voltagefor bridge rectification 0.9 x mains voltage Permissible cycle time (1 cycle = 1 x ON + 1x OFF ≥ 0.5 s (for 5 100 Nm brake) ≥ 1.0 s (for 150 Nm brake)			
79	MB+	Brake control (+)	-	-		
80	MB-	Brake control (Brake control (-)		-		
Mains	s connection	Mains voltage	Mains voltage connection for one way rectification				
		Mains connection 3	Mains connection 380 - 500 VAC ± 10%, max. 10 A				
L1 _E	L1	Mains connect	ion 1st Phase	-	-		
L2/N	L2/N	Mains connect	Mains connection 2nd Phase / N		-		
		Mains voltage	connection for bride	ge rectification	i		
		Mains connection max. 10 A	100 - 275 VAC ± 10%,				
L1 _B	L1	Mains supply 1	Ist Phase	-	-		
L2/N	L2/N	Mains supply 2	2nd Phase / N	_	-		

Connection example

44	brown	24 V DC	Connection to the 24 V output of the electronic drive technology
40	blue	AGND / 0V	Connection to the Ground of the electronic drive technology
C5	black	DIN	Digital signal (input) Connection to a digital output of the electronic drive technology
B5		DOUT	Digital signal (output) - feedback: Connection to a digital input of the electronic drive technology
80		МВ-	Brake control (-): Connection to the electromechanical brake
79		MB+	Brake control (+) Connection to the electromechanical brake
L1 _E	brown	L1 _E	Connection to L1 of the electronic drive technology for 380 500 V AC mains
L1 _E	brown	L1 _B	Connection to L1 of the electronic drive technology for 100 275 V AC mains
L1 _B	black	L2/N	Connection to N or L2 or L2/N of the electronic drive technology
L2/N			

Further documentation (www.nord.com)

Document	Name
BU 0180	Frequency inverter manual NORDAC BASE

Document	Name
BU 0200	Frequency inverter manual NORDAC FLEX

4 / 4 TI 275271510 - 0523